

Table of contents

- 1 Electromagnetic Theory
- 1.1 Introduction to Microwave Engineering
- Applications of Microwave Engineering
- A Short History of Microwave Engineering
- 1.2 Maxwell's Equations
- 1.3 Fields in Media and Boundary Conditions
- Fields at a General Material Interface 11 Fields at a Dielectric Interface
- Fields at the Interface with a Perfect Conductor (Electric Wall)
- The MagneticWall Boundary Condition
- The Radiation Condition
- 1.4 The Wave Equation and Basic Plane Wave Solutions
- The Helmholtz Equation
- Plane Waves in a Lossless Medium
- Plane Waves in a General Lossy Medium
- Plane Waves in a Good Conductor
- 1.5 General Plane Wave Solutions
- Circularly Polarized Plane Waves
- 1.6 Energy and Power
- Power Absorbed by a Good Conductor
- 1.7 Plane Wave Reflection from a Media Interface
- General Medium
- Lossless Medium
- Good Conductor
- Perfect Conductor
- The Surface Impedance Concept
- 1.8 Oblique Incidence at a Dielectric Interface
- Parallel Polarization
- Perpendicular Polarization
- Total Reflection and Surface Waves
- 1.9 Some Useful Theorems
- The Reciprocity Theorem
- Image Theory
- 2 Transmission Line Theory
- 2.1 The Lumped-Element Circuit Model for a Transmission Line
- Wave Propagation on a Transmission Line
- The Lossless Line
- 2.2 Field Analysis of Transmission Lines
- Transmission Line Parameters
- The Telegrapher Equations Derived from Field Analysis of a Coaxial Line
- Propagation Constant, Impedance, and Power Flow for the Lossless Coaxial Line
- 2.3 The Terminated Lossless Transmission Line
- Special Cases of Lossless Terminated Lines
- 2.4 The Smith Chart

- **The Combined Impedance-Admittance Smith Chart**
- **The Slotted Line**
- **2.5 The Quarter-Wave Transformer**
- **The Impedance Viewpoint**
- **The Multiple Reflection Viewpoint**
- **2.6 Generator and Load Mismatches**
- **Load Matched to Line**
- **Generator Matched to Loaded Line**
- **Conjugate Matching**
- **2.7 Lossy Transmission Lines**
- **The Low-Loss Line**
- **The Distortionless Line**
- **The Terminated Lossy Line**
- **The Perturbation Method for Calculating Attenuation**
- **The Wheeler Incremental Inductance Rule**
- **3 Transmission lines and waveguides**
- **3.1 General Solutions for TEM, TE, and TM Waves**
- **TEM Waves**
- **TE Waves**
- **TM Waves**
- **Attenuation Due to Dielectric Loss**
- **3.2 Parallel Plate Waveguide**
- **TEM Modes**
- **TM Modes**
- **TE Modes**
- **3.3 Rectangular Waveguide**
- **TE Modes**
- **TM Modes**
- **TE_{m0} Modes of a Partially Loaded Waveguide**
- **3.4 Circular Waveguide**
- **TE Modes**
- **TM Modes**
- **3.5 Coaxial Line**
- **TEM Modes**
- **Higher Order Modes**
- **3.6 Surface Waves on a Grounded Dielectric Slab**
- **TM Modes**
- **TE Modes**
- **3.7 Stripline**
- **Formulas for Propagation Constant, Characteristic Impedance, and Attenuation**
- **An Approximate Electrostatic Solution**
- **3.8 Microstrip**
- **Formulas for Effective Dielectric Constant, Characteristic Impedance, and Attenuation**
- **An Approximate Electrostatic Solution**

- **3.9 The Transverse Resonance Technique**
- **TE_{0n} Modes of a Partially Loaded Rectangular Waveguide**
- **3.10 Wave Velocities and Dispersion**
- **Group Velocity**
- **3.11 Summary of Transmission Lines and Waveguides**
- **Other Types of Lines and Guides**
- **4 Microwave Network Analysis**
- **4.1 Impedance and Equivalent Voltages and Currents**
- **Equivalent Voltages and Currents**
- **The Concept of Impedance**
- **Even and Odd Properties of $Z(?)$ and $Y(?)$**
- **4.2 Impedance and Admittance Matrices**
- **Reciprocal Networks**
- **Lossless Networks**
- **4.3 The Scattering Matrix**
- **Reciprocal Networks and Lossless Networks**
- **A Shift in Reference Planes**
- **Generalized Scattering Parameters**
- **4.4 The Transmission (ABCD) Matrix**
- **Relation to Impedance Matrix**
- **Equivalent Circuits for Two-Port Networks**
- **4.5 Signal Flow Graphs**
- **Decomposition**