## Table of contents

- List of Troubleshooting Charts (p. viii)
- List of Tables (p. ix)
- Preface and Acknowledgments to the Third Edition (p. xii)
- Preface and Acknowledgments to the Second Edition (p. xiv)
- Introduction (p. 1)
- Chapter 1 Establishing a Balanced Battery-Powered Electrical System (p. 2)
- Introduction (p. 4)
- **Batteries** (p. 5)
- Getting Down to Specifics (p. 16)
- Putting the Pieces Together (p. 35)
- Summary: A Balanced System (p. 45)
- Chapter 2 Electrical Systems for Energy-Intensive Boats (p. 46)
- Additional Energy Sources (p. 48)
- Dual-Voltage DC Systems (p. 57)
- Fuel Cells, Higher-Voltage DC Boats, and Electric Propulsion (p. 65)
- Chapter 3 Maintaining and Troubleshooting a Battery-Powered Electrical System (p. 72)
- **Batteries** (p. 74)
- Alternators (p. 85)
- Voltage Regulators (p. 104)
- **Diodes** (p. 109)
- Chapter 4 Understanding and Troubleshooting Electrical Circuits (p. 112)
- Basic Concepts and Measurements (p. 114)
- **DC Circuits** (p. 121)
- **AC Circuits** (p. 133)
- Proper Electrical Installations (p. 157)
- Chapter 5 Corrosion, Bonding, Lightning Protection, and Grounding (p. 196)
- **Corrosion** (p. 198)
- Bonding and Cathodic Protection (p. 212)
- Lightning Protection (p. 219)
- **Grounding** (p. 231)
- Chapter 6 Battery Chargers, Inverters, Wind and Water Generators, and Solar Panels (p. 236)
- Battery Chargers (p. 238)
- **Inverters** (p. 250)
- Wind and Water Generators (p. 266)
- **Solar Panels** (p. 281)
- Chapter 7 AC Generators, DC Generators, Electric Motors (DC and AC), and Electric Lights (p. 288)
- **AC Generators** (p. 290)
- DC Generators (p. 305)
- Electric Motors (p. 306)
- Electric Lights (p. 326)

- Chapter 8 Marine Electronics: Antennas and Radio Grounds,
  Electromagnetic and Radio Frequency Interference, and Saving Soaked
  Equipment (p. 338)
- Marine Electronics (p. 340)
- Antennas and Radio Grounds (p. 343)
- Electromagnetic and Radio Frequency Interference (p. 353)
- Saving Soaked Equipment (p. 360)
- Chapter 9 Diesel Engines: Operation and Maintenance, Troubleshooting, and Winter Layup (p. 362)
- Operation and Maintenance (p. 364)
- Troubleshooting Part 1: Failure to Start (p. 377)
- Troubleshooting Part 2: Operating Problems (p. 395)
- Winter Layup and Recommissioning (p. 414)
- Chapter 10 From Transmission to Propeller (p. 422)
- Transmissions and Shaft Brakes (p. 424)
- Connecting a Transmission to a Propeller Shaft (p. 437)
- **Shaft Seals** (p. 442)
- Struts, Bearings, and Propellers (p. 449)
- Chapter 11 Refrigeration and Air-Conditioning (p. 458)
- CFCs and the Ozone Hole (p. 460)
- Balancing Refrigeration Needs with Boat Use (p. 463)
- Air-Conditioning (p. 488)
- Refrigeration and Air-Conditioning: Maintenance, Troubleshooting, and Repair (p. 491)
- Charging and Topping-Off Procedures (p. 509)
- Chapter 12 Tanks, Plumbing, Toilets, and Through-Hull Fittings (p. 516)
- Tanks and Fittings (p. 518)
- **Plumbing** (p. 527)
- Marine Toilets (Heads) (p. 540)
- Through-Hulls and Seacocks (p. 560)
- Chapter 13 Pumps and Watermakers (p. 570)
- **Pumps** (p. 572)
- Pump Switches (p. 601)
- Watermakers (p. 607)
- Chapter 14 Steering Systems, Autopilots, and Wind Vanes (p. 620)
- Steering Systems (p. 622)
- **Autopilots** (p. 647)
- Wind Vane Self-Steering (p. 653)
- Chapter 15 Stoves, Cabin Heaters, Gas-Powered Water Heaters, and Lanterns (p. 662)
- **Gas** (p. 664)
- Alcohol, Kerosene, and Diesel Appliances (p. 676)
- Carbon Monoxide Poisoning (p. 684)
- Chapter 16 Blocks, Winches, Windlasses, and Bow Thrusters (p. 692)
- **Blocks** (p. 694)
- **Winches** (p. 699)

- **Windlasses** (p. 709)
- Bow Thrusters (p. 729)
- Chapter 17 Spars, Standing Rigging, and Roller Reefing (p. 730)
- **Spars** (p. 732)
- Standing Rigging (p. 748)
- Roller Reefing and Furling (p. 767)
- **Glossary** (p. 782)
- Appendix A Checklist of Winterizing Procedures (p. 790)
- Appendix B Freeing Frozen Parts and Fasteners (p. 792)
- Appendix C Tools and Spare Parts (p. 794)
- Appendix D Useful Tables (p. 797)
- **Index** (p. 805)